

RAMPpremium Quickguide

Radinpark imagesound toníque

Sarica


Part of the Imagesound Group

RAMPpremium front side



Harddrive LED

RAMPpremium back side



TECHNICAL SPECIFICATIONS

Up to 32 digital outputs (4xADAT)

2U Server 19" Rack-mounted system

Harddrive SSD 250 GB

Incl. software for automatically play-out of music playlists

Updates via LAN, download link or USB

Power s upply: 100-240V, 300W, 5 - 2,5A, 60/50Hz

Dimensions: 2U, 19", depth: 36 cm (without brackets)

CONTENT

USB thumb drive (opt.) for updates

TOSLINK cable (ADAT)

Power cable

RAMPpremium GUI manual (only if monitor is connected)

Fig. 1: Main Channel Preview



Artist / Title currently playing

Channel Output number

Green = music is playing (example 10 Channels)

Orange = channel is not assigned or the music stopped playing


Extra menu:

- · set time and clock
- · edit network configuration
- · check playlist expiry

Fig. 2: Theme Channel Preview

Theme channel selection (optional)

- · Select designated Main channel
- · Choose theme channel via sub menu and press "LAUNCH"



How to do the music updates via download link with USB thumb drive

- 1. Connect the player to the electrical power supply (rear side)
- Plug the digital audio output TOSLINK cable (2) (A to D) to

 a. your corresponding amplifier audio inputs via optional analog AD/DA converter (if needed)
 .
 - b. Your digital audio matrix/DANTE system (BNC wordclock out as slave) via optional digital converter (if needed) . LED on BNC wordclock needs a green LED
- 3. Press the POWER-Button 3 (front side). Please make sure that the power switch 4 on the rear side is also ON. Please note: If no monitor is connected, the power indicator 5 is blinking green
- 4. The system starts up. The internal software automatically loads the playlist for the current day/time and starts playing the sound files/playlist. The whole process needs appr. 20 seconds.
- 5. No sound? Restart the player. Shut down the player by pressing the on/off button and wait until the player shuts down. Start the player by pressing the on/off button again.

How to do the music updates via download link with USB thumb drive

- 1. You'll regularly receive an e-mail from Radiopark including a download link.
- 2. Click on the link and download the file.
- 3. The downloadfile/s needs to be saved on a NTFS-formatted USB thumbdrive; this step can be skipped if you have received a pre-configured USB prepared by Radiopark
- 4. The USB thumbdrive needs to be inserted into the front-USB socket 6 of the player to execute the update.
- 5. The update will run automatically.
- 6. During the update the LED **7** will be flashing blue. As soon as the update has been successfully finished the LED will be lit blue. Please remove the USB and reboot the player.
- 7. If you have several 19" servers, you may save several update files on the same USB thumbdrive. The server will identify the corresponding update.

Music updates online

- Automatic online updates require a permanent LAN connection (outgoing connection via port 22 / firewall)
- Please contact Radioapark support upon first installation to re-confirm the connection was successful and player can be accessed remotely.

Not working? - Let's see ...

- Was the file downloaded completely?
- Has your file the correct file ending .aes?
- Did you save the original file without a number in brackets (e. g. content(1).aes > wrong!)?
- Was your USB thumb drive empty before you saved the file?
- Has the file been saved as received and not been tidied up into a folder?
- Has the USB thumbdrive been ejected securely?
- Did you restart the player after the update? Restart the player by pressing the on/off button for minimum 4 seconds until the power indicator goes off.

Radiopark support

+ 49 40 / 43 09 370 support@radiopark.de

(Please tell us the 4 digit player ID on the front side of your player)

Video Guide: How to Update

