



# RAMPstream & RAMPstream BIG

## Quickguide

*Radiopark*

**imagesound**

tonique



*Sonica*

Part of the Imagesound Group

# RAMPstream



# RAMPstream BIG



## SYSTEM REQUIREMENTS AND TECHNICAL DATA

	RAMPstream	RAMPstream BIG
Connections	RJ45-LAN, 1 x Stereo-Out 3.5mm jack	RJ45-LAN, 4 x Stereo-Out 3.5mm jack
Power Supply	100-240V 50-60Hz AC/50W max. (extern)	230V 50-60 Hz AC/200W max.
Music-Cache	360 Hours	1100 Hours
IP-Configuration	DHCP	DHCP
Bandwidth	30-360 kbit/s (cached/uncached)	50-1500 kbit/s (cached/uncached); Ports outgoing
Ports	outgoing 80/443 TCP, 1194 UDP	outgoing 80/443 TCP, 1194 UDP
Dimensions	197mm x 197mm x 32mm	480mm x 45mm x 250mm (19"-1HE)
Weight	1,33kg	4,44kg

**Scope of delivery: Power supply, network and audio cable**

## INSTALLATION

The tonique player needs to be connected to the power supply ❶, the Internet ❷ and your audio system ❸. After 30 seconds the music will start playing, the Power LED shows a green or a blue light.

## MUSIC CONTROL

You can access the remote control for volume and station selection via Browser [player.tonique.com](http://player.tonique.com).

**The device can only be controlled with an active internet connection!**

Alternatively you can use a mobile app to control the music.

app control:



video guide for the app controlling:



## TROUBLE SHOOTING

### **The Player is offline**

Is the tonique player switched on?

Does the tonique player have a connection to the internet?

Are there any network problems in the house?

Can the device use the specified ports on our servers?

### **The Power LED is off**

Is the tonique player connected to the power supply? Is the power supply or power cable OK?

Was there a power outage?

### **No music / background noise**

Is the tonique player switched on?

Has the stereo / amplifier / audio matrix been checked? Is the correct audio source set?

Has the volume of the tonique player and the playback system been set correctly?

Is the audio cable damaged?

Do a headphone test to make sure that the tonique player is playing music (connect headphones to the tonique player audio output)

### **Tonique Support**

+49 89 69 39 58 04

[contact@tonique.com](mailto:contact@tonique.com)